







Legend

- △ JPL Deep Multi-Port Monitoring Well
- JPL Shallow Monitoring Well
- City of Pasadena Monitoring Well
- ⊕ Municipal Production Well

LCID = La Canada Irrigation District
VWC = Valley Water Co.
LAWC = Lincoln Avenue Water Co.
RCL&W = Rubio Canon Land & Water Co.
LFWC = Las Flores Water Co.
All others are City of Pasadena

1: Screen Number for Wells in this Aquifer Layer
-- Not Detected
NS Not Sampled

--- JPL Thrust Fault
— JPL Property Line

Notes: 1. No detections were above the MCL, so the contaminant concentrations were not contoured.
2. All units reported in µg/L.

800 400 0 800

SCALE IN FEET

Base Map Source: USGS, 7.5' Topographic Map
Pasadena, CA 1988, Revised 1988, 1994.

FIGURE 3-7

CONCENTRATIONS OF TETRACHLOROETHENE
IN AQUIFER LAYER 1

APRIL 2001

Jet Propulsion Laboratory
Pasadena, California

SOTA Environmental Technology, Inc.









